

1240L - BS1240L



700690 - 700699

Bartscher GmbH
Franz-Kleine-Str. 28
D-33154 Salzkotten
Germany

Phone: +49 5258 971-0

Fax: +49 5258 971-120

Technical Support Hotline: +49 5258 971-197

www.bartscher.com



Version: 1.0

Date of preparation: 2025-06-23

Original instruction manual

1	Safety	2
1.1	Explanation of Signal Words	2
1.2	Safety instructions	3
1.3	Intended Use	5
1.4	Unintended Use	6
2	General information	7
2.1	Liability and Warranty	7
2.2	Copyright Protection	7
2.3	Declaration of Conformity	7
3	Transport, Packaging and Storage	8
3.1	Delivery Check	8
3.2	Packaging	8
3.3	Storage	8
4	Technical Data	9
4.1	Technical Specifications	9
4.2	List of Components of the Appliance	11
4.3	Functions of the Appliance	13
5	Installation and operation	13
5.1	Installation	13
5.2	Operation	16
6	Cleaning and Maintenance	22
6.1	Safety Instructions for Cleaning	22
6.2	Cleaning	23
6.3	Maintenance	23
7	Possible Malfunctions	24
8	Disposal	26



Read these instruction manual before using the appliance and keep it available at all times!

This instruction manual contains information about installation, operation and maintenance of the appliance and constitutes an important source of information and reference guide. The knowledge of all operational and safety instructions included in this manual is a prerequisite for safe and proper handling of the appliance.

Read this instruction manual before you use the appliance and particularly before you start the appliance to prevent injury or damage. Incorrect use may cause damage.

All important information contained in the operating instructions must be available to the appropriate staff at all time. The operator shall be responsible for their availability.

In addition to the operating instructions, you must comply with the general, legal and other applicable regulations for occupational safety and environmental protection.

EN

1 Safety

This appliance has been manufactured in accordance with technical standards currently in force. However, the appliance may be a source of hazards if used improperly or contrary to its intended purpose. All persons using the appliance must consider information included in this instruction manual and observe safety instructions.

1.1 Explanation of Signal Words

Important safety instructions and warning information are indicated in this instruction manual with appropriate signal words. You must strictly follow the instructions, to prevent accidents, personal injuries and property damages.



DANGER!

The signal word **DANGER** warns against hazards that lead to severe injuries or death if the hazards are not avoided.



WARNING!

The signal word **WARNING** warns against hazards that may lead to moderate or severe injuries or death if the hazards are not avoided.



CAUTION!

The signal word **CAUTION** warns against hazards that may lead to light or moderate injuries if the hazards are not avoided.

IMPORTANT!

The signal word **IMPORTANT** indicates possible property damages, which may occur if safety instructions are not observed.

NOTE!

The symbol **NOTE** indicates subsequent information and guidelines for the user on usage of the appliance.

EN

1.2 Safety instructions

Electrical Current

- Too high a mains voltage or incorrect installation may cause electric shock.
- The appliance may be connected only if data on the rating plate correspond with the mains voltage.
- To avoid short-circuit, the appliance should be kept dry.
- If there are malfunctions during operation, disconnect the appliance from the power supply.
- Do not touch the appliance's plug with wet hands.
- Never take hold of the appliance if it has fallen into water. Immediately disconnect the appliance from the power supply.
- Any repairs or housing opening may be carried out by professionals and relevant workshops only.
- Do not transport the appliance, holding it by the power cord.
- Do not allow the power cord to come into contact with heat sources or sharp edges.

- Do not bend, pinch nor knot the power cord.
- Always completely unwind the power cord.
- Never place the appliance or other objects on the power cord.
- Always take hold of the plug to disconnect the appliance from the power supply.
- Check the power cord regularly for damage. Do not use the appliance if the power cord is damaged. If this cable is damaged, it must be replaced by customer service or a qualified electrician in order to avoid dangers.

Fire hazard / flammable materials hazard / explosion hazard!

- Do not use any electric devices in the appliance.
- Do not store nor use petrol or other flammable liquids and gases in the vicinity of this or any other appliance. Those gases may cause fire or explosion hazard.
- Do not put into the appliance any explosive materials, like sprays filled with flammable propellants. Contents of containers filled with flammable gases and liquids may leak in low temperatures, and the contents may catch fire from sparks generated by an electric appliance. Explosion hazard!
- In the case of coolant leakage, pull the plug from the socket. Remove all sources of ignition in the vicinity, ventilate room and contact technical service. Avoid coolant getting in contact with eyes, as it may cause serious eye damage.
- Never use any flammable liquids for cleaning the appliance or its parts. Gases released may cause fire or explosion hazard.
- In the case of fire, disconnect the appliance from the power supply before attempting adequate fire-extinguishing actions.
- Never attempt to extinguish fire with water if the appliance is connected to the power supply. Following extinction of fire, ensure sufficient fresh air inflow.
- Defrosting process may not be sped up with mechanical means or heat energy sources (candles or heaters) nor with any other means. Vapour produced may cause short-circuit and too high temperatures may damage the appliance.
- All ventilation slots should not be obstructed during operation.
- Never attempt to damage cooling installation of the appliance.

Operator's responsibility

The operator is responsible for complying with the currently applicable laws, regulations, ordinances and existing national regulations on accident prevention, environmental protection, as well as the internal operation, operating and safety instructions that apply at the respective installation site.

Obligations of the operator:

Safety

- Operate the appliance and its components only in a technical condition that does not raise any objections, with functional protective and safety elements.
- Prepare risk assessment at work positions.
- Provide instruction and regular staff training. Pay special attention to and observe the section concerning safety and any safety hints.
- Provide suitable personal protective equipment (PPE)
- Observe the intervals of maintenance and cleaning.
- Document training/instructions, replacement of components.

Operating Personnel

- The appliance may only be operated by qualified personnel and trained specialist personnel.
- This appliance may not be operated by persons (including children) with limited physical, sensory or mental capabilities, nor by persons with limited experience and/or limited knowledge.
- Children should be supervised to ensure that they are not playing with or switching on the appliance.

Improper Use

- Unintended or prohibited use may cause damage to the appliance.
- The appliance may only be used when its technical condition is flawless and allows for safe operation.
- The appliance may only be used when all connections are executed according to rules of law in force.
- The appliance may only be used when it is clean.
- Use only original spare parts. Never attempt to repair the appliance on your own.
- Do not introduce any changes in the appliance nor modify it.

- Do not drill hole in the appliance nor install any objects on it.
- Do not place any heavy objects on the appliance.

1.3 Intended Use

This appliance is only intended for use described in the operating instructions, with the supplied and approved components.

Any other use is considered against the intended purpose. The manufacturer shall not be liable for any damage due to unintended use. In such cases the responsible party shall only be the user/operator.

The following is an intended purpose:

- Cooling and preparation of suitable beverages and food products.

1.4 Unintended Use

An unintended use may lead to personal injuries or property damages caused by hazardous voltage, fire or high temperature. The appliance may only be used to perform tasks described in this instruction manual.

The following is an unintended use:

- Storing flammable or explosive objects and liquids, such as ether, petroleum or adhesives;
- Storing explosive materials, like sprays filled with flammable propellants;
- Storing pharmaceutical products or preserved blood;
- Storing live pets.

2 General information

2.1 Liability and Warranty

The appliance was built in accordance with the current state of the art and recognized technical safety principles. Nevertheless, during its use, there may be a threat to the health and life of the user or bystanders, or the danger of damage to the device or other assets. Warranty and liability claims for personal injury/property damage as well as defects at work are excluded if they can be attributed to one or more of the following causes:

- Use against the intended purpose
- Failure to follow/disregard the instructions and all related information
- Unauthorized structural or technical changes to the device
- Engaging insufficiently trained and insufficiently qualified personnel
- Operation with defective or incorrectly installed safety and protective devices
- Inadequate maintenance or cleaning
- Faults not fixed
- Use of prohibited media, cleaning agents, etc.
- Use of unauthorised spare parts
- Errors in operation or other misuse
- Disasters caused by foreign objects or force majeure
- Destruction of the type plate and stickers relevant for operation and safety

EN

2.2 Copyright Protection

This instruction manual, and texts, drawings and images included in it, as well as its other components are copyright protected. It is prohibited to reproduce this instruction manual (including its excerpts), in any form and by any means, and to use and/or transfer its content to third parties without manufacturer's written permission. Violation of the above results in obligation to pay compensation. We reserve the right to claim further damages.

2.3 Declaration of Conformity

The appliance meets the currently applicable standards and guidelines of the European Union. We confirm the above in the EC Declaration of Conformity. We may provide relevant Declaration of Conformity upon request.

3 Transport, Packaging and Storage

3.1 Delivery Check

Immediately upon reception, check the delivery for completeness and possible shipping damage. In the case of visible transport damage refuse to accept the appliance or accept it conditionally. Mark and note the scope of damage in shipping documents/consignment list of the shipping company and lodge a complaint. Concealed damage must be reported immediately upon its discovery, as compensation claims may only be filed within applicable time limits.

If you find that parts or accessories missing, please contact our Customer Service Department.

3.2 Packaging

Do not dispose of the appliance cardboard box. It may be used to store the appliance when relocating or when shipping the appliance to our service point in the case of any damages.

The packaging and its elements are made of recyclable materials. Particularly, these are: plastic films and bags, cardboard box.

EN

When disposing of the packaging, observe applicable domestic regulations. Recyclable packaging materials should be recycled.

3.3 Storage

Leave the packaging closed until installation of the appliance; observe external indications concerning method of placing and storage. Store the packaging in the following conditions only:

- in closed rooms;
- in dry and dust-free surrounding;
- away from aggressive agents;
- in a location protected against sunlight;
- in a location protected against mechanical shocks.

In the case of extended storage (over three months), make sure you check the condition of the packaging and the parts regularly. If needed, replace the packaging with a new one.

4 Technical Data

4.1 Technical Specifications

Version / characteristics

- State at delivery:
 - 700690: assembled for ready to use
 - 700699: assembly kit (easy assembly)**
- Cooling: compressor
- Thermostat
- Temperature control: digital
- Control: electronic, knob
- Automatic defrost function
- Evaporation of condensed water
- Insulation: polyurethane, 60 mm
- Digital display
- ON/OFF switch
- Door type: leaf door
- Number of doors: 1
- Door hinge: on the right
- Appliance locked with a key
- Panic lock
- Preparation for bearing rails, grates, suspension device, access ramp (not included in the scope of delivery)

****NOTE**

To install the 700699 / BS1240L mini refrigerator, please observe the indications provided in the enclosed assembly instruction.

Name:	Mini cold room 1240L
Art. No.:	700690
Material:	Steel plate, PVC coated
Inner material:	Aluminium, stainless steel base
Volume, in L:	1240
Temperature range, min.– max., in °C:	2 - 10
Ambient temperature, min.– max., in °C:	16 - 38
Coolant/amount, in kg:	R290 / 0,130
Climate class:	4
Power load:	0,571 kW / 230 V / 50 Hz
Internal dimensions (W x D x H), in mm:	820 x 860 x 1.760
Dimensions (W x D x H), in mm:	980 x 1.040 x 2.200
Weight, in kg:	158,2

EN

Name:	Mini cold room BS1240L
Art. No.:	700699
Material:	Steel plate, PVC coated
Inner material:	Aluminium, stainless steel base
Volume, in L:	1240
Temperature range, min.– max., in °C:	2 - 10
Ambient temperature, min.– max., in °C:	16 - 38
Coolant/amount, in kg:	R290 / 0,130
Climate class:	4
Power load:	0,571 kW / 230 V / 50 Hz
Internal dimensions (W x D x H), in mm:	820 x 860 x 1.760
Dimensions (W x D x H), in mm:	980 x 1.040 x 2.200
Weight, in kg:	158,2

We reserve the right to implement technical modifications.

4.2 List of Components of the Appliance



EN

Fig. 1

- | | |
|------------------------|---|
| 1. Refrigerating unit | 2. Digital temperature controller |
| 3. Door | 4. Panic lock |
| 5. Door seal | 6. Stainless steel bottom |
| 7. Cooling compartment | 8. Ventilation openings of the refrigerating unit |

Accessories (not included)

Bearing rails

- Set elements: 4 bearing rails
- Material: stainless steel
- Number of shelf levels: 8
- Clearance between shelves: 200 mm
- Important hint: mini-freezer requires 4 bearing rails
- Dimensions: W 1,500 x D 40 x H 25 mm
- Weight: 5.92 kg

Art. No.: 700593



Suspension device

- Set elements: 2 bearing rails, suspension pipe (possibility to set level in 5 positions)
- Material: stainless steel, plastic
- Length of bearing rails: 850 mm
- Pipe dimensions: Ø 30 mm / length: 830 mm
- Max. load-bearing capacity: 150 kg
- Distance from the bottom: 1700 mm
- Dimensions: W 830 x D 30 x H 30
- Weight: 1.6 kg

Art. No. 700595



Grate

- Material: steel, zinc-plated
- Max. load-bearing capacity: 20 kg
- Dimensions: W 830 x D 870 x H 40 mm
- Weight: 4.7 kg

Art. No. 700592



NOTE:

For the assembly of accessories the M5x16 mm V2A button head screws are required.

Access ramp

- Material: stainless steel
- Max. load-bearing capacity 130 kg
- Dimensions: W 845 x D 125 x H 30 mm
- Weight: 1.55 kg

Art. No. 700597



4.3 Functions of the Appliance

The appliance is designed for cooling and storage of suitable beverages and food products.

5 Installation and operation

5.1 Installation



CAUTION!

Incorrect installation, positioning, operation, maintenance or misuse of the appliance may lead to personal injury or property damage.

Positioning and installation, as well as repairs may be performed by authorised technical service only and in compliance with the applicable national law.

NOTE!

The manufacturer disclaims all liability and provides no warranty for damages, which may be attributed to non-observance of regulations or incorrect installation.

Unpacking / Positioning

- Unpack the appliance, remove all external and internal packaging elements and shipment safeguards.



CAUTION!

Choking hazard!

Prevent children from accessing packaging materials, for instance: plastic bags and EPS elements.

- If the appliance is covered with a protective film, remove it. Remove the film slowly, so no glue residues are left. Remove any glue residues with the use of a suitable solvent.
- Be careful not to damage the rating plate and warning labels affixed to the appliance.
- **Never** place the appliance in humid or wet environment.
- Place the appliance in a way making the connections easily accessible, so that they may be quickly disconnected if such a need arises.
- When selecting the installation site, please consider the following items:
 - The mounting surface must be even, sufficiently load-bearing, waterproof, dry and resistant to high temperatures.
 - Make sure that the designated escape routes are clear.
 - Ensure a stable position.
 - Allow sufficient space for work, maintenance and cleaning.
 - Leave the supply and exhaust air vents, if any, free.
 - Comply with applicable technical and building regulations.
- Do not place the appliance in direct sunlight or in the vicinity of heat sources (cooker, radiator, heating devices, etc.). Heat sources may negatively affect power consumption, and restrict functions of the appliance, too.
- In order to avoid damage to the compressor, do not tilt the appliance more than 45° when positioning or transporting it.
- The mini cold room should be positioned in a way allowing for sufficient space for opening the door and operation, as well as allowing for sufficient air circulation around the appliance.
- Leave at least 50 cm clearance from ceiling and 10 cm clearance from walls and other objects.

Installation and operation

- Do not position the appliance in high humidity locations. Air relative humidity in the place of installation should not exceed 40 %. Excessive humidity may cause rust and negatively influence the refrigerating efficiency of the device.
- The appliance should be installed only in rooms, in which ambient temperature falls within the range of 16 °C – 38 °C.
- To install the appliance, perform the following steps:
 - Remove the packaging of the appliance, except for the pallet.
 - Lift the appliance with the lift truck and move it to the planned installation location. Be careful not to damage the appliance. Control the stability in order not to lose the balance of the appliance.
 - Do not drag nor push the appliance, as it may fall down. This may also cause the damage to external elements or feet.
 - As soon as the appliance is in the planned installation location, remove the pallet.
 - Level the appliance by screwing in or out the feet.
 - Remove the protective film from the appliance at the end.

Power supply connection

- Verify if technical data of the appliance (see rating plate) correspond with the local electric power grid specification.
- Connect the appliance to a single, properly grounded mains socket with protective contact. Do not connect the appliance to a multi-socket.
- The power cord should be laid in a way preventing anyone from threading on it or tripping against it.
- Prior to first use, the appliance should be installed and left standing upright for at least 2 hours, before it is connected to power supply.
- After a power failure or when the plug is removed from the socket, do not reconnect the appliance to power supply for at least 5 minutes.

5.2 Operation

Tips for the user

- Prepare the required food products and dishes and place them in suitable containers.
- Do not place warm dishes in the mini cold room; cool them down to ambient temperature first.
- Make sure all the products are covered or packed.
- Raw dishes should always be stored separately from the ready-made dishes.
- Do not overfill the mini cold room. Make sure the air circulation in the appliance is never obstructed, and the stored dishes are arranged with suitable clearance from one another: too little a distance affects negatively the effects of cooling.
- Spilled beverages and/or dishes should be wiped out immediately.
- Remove food products and dishes from the mini cold room as required, and then swiftly close the door.
- To limit loss of cold air minimize the opening time of door during operation. Also, do not open the door too frequently.
- If possible, in the event of a sudden power failure, avoid opening doors in order to avoid loss of cool air.
- The power supply to the appliance should never be interrupted for more than 10 minutes.
- If the appliance is switched off for a longer period of time, the door should remain open.

EN

Preparation of the appliance

1. Before the first use, clean the appliance and its accessories observing the instructions in section **6 'Cleaning'**.
2. To end with, thoroughly dry the appliance and accessories.
3. Close the device door.
4. Plug the device into a suitable single socket.
5. Turn the appliance on with the ON/OFF button of the digital temperature controller by pressing it and holding it pressed for at least 5 seconds.

The pre-set temperature is shown on the digital display.

The ❄️ LED cooling indicator and the ℃ temperature indicator are lit.

6. Place the food products or the prepared dishes only after the appropriate cooling capacity has been reached.

Features of Operating Elements and Displays



Key	Features
	Switching the temperature controller ON or OFF
SET	Showing the set value, selection of parameters in the programming mode or confirmation of the process
	Displaying the highest stored temperature, selection of parameter code in programming mode, increasing the displayed value
	Displaying the minimum stored temperature, selection of parameter code in programming mode, decreasing the displayed value
	Manual start of defrosting
	Switching the internal LED lighting of the appliance on or off

LED Indicators

The LED indicators in the digital display show the status of the active function:

LED	Activation status	Meaning
	illuminates	LED lighting is on
	illuminates	activated compressor
	flashes	in delay
	illuminates	defrosting in progress
	flashes	defrosting delay
	illuminates	fan activated
	flashes	delay after defrosting
AUX	illuminates	connection with the digital input of the thermostat failed (wiring or components)
	illuminates	alarm is activated
	illuminates	continuous cycle active
	illuminates	energy-saving mode active
	illuminates	degrees Celsius temperature unit indicator light
	flashes	in programming mode
	illuminates	degrees Fahrenheit temperature unit indicator
	flashes	in programming mode

Settings

Switching the Appliance into ON / Standby Mode

1. Press and hold the  key pressed for 2 seconds.

The appliance switches from the ON mode into the Standby mode, and vice versa.

When the key is being held pressed, the LED blinks, signalling the change of status.

Displaying the Lowest Temperature

1. Press and release the  key.

The 'Lo' message is displayed, followed by the minimum registered temperature.

2. To restore standard display, press the  key again and hold it for 5 seconds.

Displaying the Highest Temperature

1. Press and release the  key.

The 'Hi' message is displayed, followed by the highest registered temperature.

2. To restore standard display, press the  key again and hold it for 5 seconds.

EN

Resetting the Minimum or Maximum Registered Temperature

1. Press the **SET** key and hold it for over 3 seconds. During that time the lowest and the highest temperatures are displayed.

The digital display shows a message (rSt).

To confirm the process, the 'rSt' message starts to blink and the current temperature is being displayed.

Displaying the Set Value

1. Press the **SET** key briefly.

The set value is being displayed.

2. Press the **SET** key again or wait 5 seconds, to return to the previous message.

Changing the Set Value (i.e. the Required Temperature)

1. Press the **SET** key and hold it for over 5 seconds.

The set value is displayed and the  or  LED indicator flashes on the digital display.

2. The displayed value may be decreased or increased with the  or  key until the digital display shows the required value.
3. Confirm the new set value with the **SET** key or wait 10 seconds — then, the value will be stored automatically.

Automatic defrosting

The appliance defrosts automatically 4 times over a 24-hour period. The timer initiates with the first activation.

1. If there is a need for the change of automatic defrosting phases, press the  key and hold it for more than 3 seconds.

The digital display shows the  symbol.

The defrosting cycle is immediately initiated; in such a case, the subsequent defrosting cycle is executed after 6 hours.

Manual Defrosting

Additionally, aside of the automatic defrosting, manual defrosting may be activated any time.

1. Press the  key and hold it pressed for at least 3 seconds.

The manual defrosting is initiated.


The digital display shows the  symbol.

NOTE!

Water generated during defrosting evaporates automatically.

Key combinations

Concurrent pressing of two of the below keys enable activation/deactivation of a number of functions.



Locking or unlocking of the temperature controller keys:

- in order to lock, press both keys concurrently and hold them pressed for more than 3 seconds; the digital display shows 'Pof'
- in order to unlock, press again both keys concurrently and hold them pressed for more than 3 seconds; until the digital display shows 'Pon'



Moving to the programming mode:

- press both keys concurrently and hold them pressed for 3 seconds; When the °C or °F LED indicators flash, subsequent settings may be introduced



Exiting the programming mode and returning to the previous message:

- press both buttons concurrently or wait for 15 seconds to leave the programming mode and return to the previously displayed message (value of temperature inside the appliance)

NOTE!

Subsequent settings or parameter changes should be introduced by service personnel only.

EN

Switching the Internal LED Lighting On/Off

1. Press and release the  key.
Internal LED lighting is switched on.
2. Press the  key again.
The internal LED lighting is switched on.

Switching the appliance off

1. If the appliance is not to be used any more, it should be switched off with the ON/OFF button at the temperature controller.
2. Disconnect the appliance from the mains socket (pull the plug out).

6 Cleaning and Maintenance

The operator must ensure that the device and its safety components are kept in good condition. Control and safety systems should be checked for their effectiveness.

Maintenance, cleaning and repairs must only be carried out by suitably trained and specialised personnel.

If the safety devices need to be removed for maintenance, cleaning and repair, they should be reinstalled immediately after completion and their function should be checked.

All maintenance and cleaning work must be carried out in accordance with the operating instructions at the specified intervals.

6.1 Safety Instructions for Cleaning

- Before cleaning, disconnect the appliance from the power supply.
- Leave the appliance to cool down completely.
- Make sure water does not enter the appliance. Do not immerse the appliance in water or other liquids during cleaning. Do not clean the appliance with a pressurized water jet.
- Do not use any sharp or pointed, nor metal implements (knife, fork, etc.). Sharp or pointed implements may damage the appliance, and when in contact with live parts, they may cause electric shock.
- For cleaning, do not use any scouring agents that contain solvents nor corrosive cleaning agents. They may damage the surface.

6.2 Cleaning

1. Clean the appliance regularly.
2. Remove all objects from the appliance and store them temporarily in a cool room.
3. Wash the interior of the appliance and the shelves regularly with warm water, using soft cloth and mild washing agent. Rinse with clean water to remove all traces of the cleaning agent.
4. The interior of the appliance should be wiped regularly (once a month) with a food-grade disinfectant.
5. Clean the exterior of the appliance with a soft, damp cloth and a mild cleaning agent; wipe with a cloth moistened in water.
6. Clean the door and the door seal of the appliance with a soft, damp cloth and a mild cleaning agent.
7. Dry washed surfaces thoroughly afterwards.
8. After cleaning, leave the door open for the appliance to dry completely.
9. Make sure the ventilation openings are always clean and free of dust. To remove the soiling, use the vacuum cleaner or a soft brush.
10. If the appliance is not to be used for a longer period of time, clean it according to the instructions above. Leave the appliance open to prevent generation of unpleasant odours inside.

EN

6.3 Maintenance

The following operations should be regularly performed by a qualified specialist:

- cleaning the condenser with suitable tools (vacuum cleaner or soft brush);
- checking of electrical connections;
- checking of the thermostat and the sensor.

7 Possible Malfunctions

The table below contains descriptions of possible causes and solutions to malfunctions or errors during operation of the appliance. The works may only be performed by suitably qualified technical personnel.

When malfunction cannot be removed, contact the technical service. In such a case, provide article number, model and serial number. You will find this information on the rating plate.

Error	Possible Cause	Solution
No functions available	Plug improperly inserted into a socket.	Remove the plug and insert it properly in the socket.
	Electric power supply safety fuse damaged.	Check the fuse, connect the appliance to another socket.
	No power supply.	Check electric power supply.
	Damaged socket.	Plug the appliance into another socket.
	Damaged mains power plug.	Contact the service company.
	Damaged temperature controller.	Contact the service company.
Insufficient cooling efficiency	Condenser obstructed with dust.	Clean the condenser thoroughly.
	Direct sunlight or heat sources in immediate vicinity.	Move the appliance away from heat sources.

Possible Malfunctions

Error	Possible Cause	Solution
Insufficient cooling efficiency	Poor air circulation around the appliance.	Keep sufficient clearance from walls or other objects.
	Ambient temperature too high.	Provide for good air circulation in the installation location or install the appliance in a cooler room.
	Food products that are too warm are placed in the appliance.	Remove hot food products from the appliance.
	Too little clearance between objects inside the appliance or too many objects in the appliance.	Provide for sufficient clearance between objects inside the appliance; remove the excess of objects.
Strange or loud noises	The appliance is not placed on even surface.	Place the appliance on even surface.
	Appliance touches walls or other objects.	Keep sufficient clearance from walls or other objects.
	The screws that mount the compressor to the base are loose.	Tighten the mounting screws.

8 Disposal

Electrical Appliance



Electric appliances are marked with this symbol. Electrical appliances must be disposed of and recycled in a correct and environmentally friendly manner. You must not dispose of electric appliances with household waste. Disconnect the appliance from the power supply and remove power cord from the appliance.

Electrical appliances should be returned to designated collection points.

Coolant

The propellant used in the appliance is flammable. It should be utilised pursuant to national regulations in force.